

## **Operating Instruction**




- Easy to Read LCD Display
- According to 86/217/EEC
- Four Units Choice (PSI, BAR, KPA, KGF)
- Prolongs Tire Life

Manufacturer reserves the right to change product features at any time.



## **BATTERY INSTALLATION INSTRUCTION**




Peel back rubber sleeve



Pry the cover open then pull cover out (care to hold down cover)



Install 2 AAA batteries in indicated orientation



Place the battery cover along the slot, snap battery cover shut



Reinstall rubber sleeve



- 1. Remove tire valve cap.
- 2. With clip-on air chuck lever depressed, firmly press chuck onto tire valve stem and release lever, ensure that no air leaks.
- **3. On:** Tire inflator will turn on automatically and displays the tire pressure. Press the button 3 seconds to turn on the inflator, if no work, the inflator will be turned off automatically 90 seconds later.
- **4. Light:** When the inflator is on, press the button to turn on the backlight, so to read the pressure easily in darkness, the backlight will extinguish automatically in 5 seconds.
- **5. Unit:** Press button above 3 seconds, enter unit change mode, then press button shortly to choose the desired unit. The unit chosen will be default unit for following usage.
- **6.** The inflator's battery is 2\*AAA, if the voltage is below 2.4V, the low battery signal on the top left will be flashing continuously, to remind user to change the battery.

BATTERY CHANGE: remove rubber cover and find the battery cover on the upper right side. Remove the cover and change the batteries.

**7.** Measuring Range: 0.5-12Bar (7-174Psi). Reading Accuracy is 0.01Bar (0.1Psi). When air pressure is above 17Bar (250Psi), LCD displays '----'.



This Tire Inflator has been tested in normal working environment according to EU standard 86/217/EEC

## Allowable tolerance

- +/-0.08 bar up to and including 4 bar
- +/-0.16 bar between 4 bar and 10 bar inclusive
- +/-0.25 bar greater than 10 bar

Important: To avoid the risk of personal injury, esp. to the eyes, face or skin, DO NOT direct the stream at any person.

